


STAR-CAST MOUNTING SYSTEM (incl. Star-Cast Hoop) Universal Type w/o MTB30 Bracket



Star-Cast Mounting System Universaal type

| Hoop Diameter | Model No. |
|---------------|-----------|
| 8" | MCM8FP |
| 10" | MCM10FP |
| 12" | MCM12FP |
| 13" | MCM13FP |
| 14" | MCM14FP |
| 15" | MCM15FP |
| 16" | MCM16FP |

1-1 Star-Cast Mounting Unit w/o Star-Cast Hoop

| Hoop Diameter | Model No. |
|---------------|-----------|
| 8" | MCM8P |
| 10" | MCM10P |
| 12" | MCM12P |
| 13" | MCM13P |
| 14" | MCM14P |
| 15" | MCM15P |
| 16" | MCM16P |

1-2 Star-Cast hoop

| Hoop Diameter | Model No. |
|---------------|--------------------|
| 8" | MDH8-4F (4 holes) |
| 10" | MDH10-6F (6 holes) |
| 12" | MDH12-6F (6 holes) |
| 13" | MDH13-6F (6 holes) |
| 14" | MDH14-8F (8 holes) |
| 15" | MDH15-8F (8 holes) |
| 16" | MDH16-8F (8 holes) |

A Floating unit

| Hoop Diameter | Model No. |
|----------------|-----------|
| 8" & 10" | MCM-50FS |
| 12" & 13" | MCM-60FS |
| 14", 15" & 16" | MCM-80FS |

A-1 ANT5WB Acorn hex nut w/washers

A-2 Rubber bolt

| Hoop Diameter | Model No. |
|----------------|-----------|
| 8" & 10" | MCM-RB50 |
| 12" & 13" | MCM-RB60 |
| 14", 15" & 16" | MCM-RB80 |

A-3 MCM-RNT Rubber nut

B B615ANT6WB Bolt, washer & nut assembly

C MCM6UP Base plate w/spacer for Star-Cast 6 hole type

MCM48UP Base plate w/spacer for Star-Cast 4 & 8 hole type

C-1 MCM-RP Rubber spacer